THREAD SIZE CHART - HANDY LIST TO HELP YOU IDENTIFY THE THREAD YOU REQUIRE . SIMPLY MEASURE THE INSIDE DIAMETER OF ANY FEMALE THREADED ITEM, OR THE OUTSIDE DIAMETER OF ANY MALE THREADED ITEM , AND THEN LOOK DOWN THE CENTRE COLUMN TO SEE WHICH THREAD SIZE YOU HAVE : -

INSIDE DIAMETER OF FEMALE THREAD	BSP THREAD	OUTSIDE DIAMETER OF MALE THREAD
8.7mm	1/8"	9.3mm
11.5mm	1/4 "	12.9mm
15.2mm	3/8"	16.2mm
18.8mm	1/2"	20.2mm
24.6mm	3/4"	26.2mm
30.4mm	1"	33.0mm